

Service Manual

Color Television

Simplified Manual
(NA8)

Panasonic

Models	Chassis
CT-2707DF	TP338
CT-2707DUF	TP338
CT-27D12DF	SP338
CT-27D12DUF	SP338
CT-27D32F	RP338
CT-27D32UF	RP338
CT-3207DF	QP341
CT-3207DUF	QP341
CT-32D12DF	TP341
CT-32D12DUF	TP341
CT-32D32F	GP341
CT-32D32UF	GP341
CT-36D12DF	KP342
CT-36D12DUF	KP342
CT-36D32F	HP342
CT-36D32UF	HP342
SP-3235F	RP341
SP-3235UF	RP341


This simplified service manual is issued to **add** listed models to the main service manual order No. **MTNC000417C1 (CT-27D10B)**. A set of unique schematics and a complete parts list are included in this simplified manual. Alignment procedures, additional squematics, dissassembly procedures are available for 27" models in simplified order No. **MTNC010201A1 (CT-27D11E)** and for 32" and 36" models in simplified order No. **MTNC010305A1 (CT-32D11E)**. Please file and use this simplified service manual together with simplified service manual order No. **MTNC010201A1**, simplified order No. **MTNC010305A1** and main service manual, order No. **MTNC000417C1**.

"WARNING! This service manual is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. **Products powered by electricity should be serviced or repaired only by experienced professional technicians.** Any attempt to service or repair the product or products dealt with in this service manual by anyone else could result in serious injury or death."


The service technician is required to read and follow the **"Safety Precautions"** and **"Important Safety Notice"** in this Manual.

Panasonic®


Copyright 2002 by Matsushita Electric Corporation of America. All rights reserved. Unauthorized copying and distribution is a violation of law.















DIFFERENCE LIST			
CIRNO	TNP2AH017AJ	TNP2AH017AK	TNP2AH017AL
R026	ERJ6GEYJ223V	NOT USED	ERJ6GEYJ183V
R027	ERJ6GEYJ103V	ERJ6GEYJ103V	ERJ6GEYJ223V
R574	ERG3FJ220H	ERG2FJ270H	ERG3FJ220H














- 43 -























Panasonic®