

A

B


C

D

E

F

G

PTACT SWITCH (1) P.C.B.
(REPX0231G)**D**TACT SWITCH (2) P.C.B.
(REPX0231G)