


A
B
C
D
E
F



A INPUT/OUTPUT TERMINAL

Left Channel Phono Signal

