



F TACT SWITCH CIRCUIT

— : -B SIGNAL LINE — : +B SIGNAL LINE




H REMOTE SENSOR CIRCUIT

— : +B SIGNAL LINE



G MUSIC PORT CIRCUIT

: MAIN SIGNAL LINE : MUSIC PORT SIGNAL LINE



SA-AK770EB/EG TACT SWITCH/MUSIC PORT/REMOTE SENSOR CIRCUIT