

REF NO. MODE	IC503																			
CD PLAY	5.2	0	0	0	0															
STANDBY	5.2	0	0	0	0															
REF NO. MODE	IC551																			
CD PLAY	0	0	0	2.6	0	5.2	3.4	0	1.3	1.7	1.7	1.7	3.3	3.4	0	0				
STANDBY	0	0	0	2.6	0	5.2	3.4	0	1.3	1.7	1.7	1.7	3.3	3.4	0	0				
REF NO. MODE	IC552																			
CD PLAY	1.7	1.7	0.9	1.7	3.3	0	0	5.2	5.2	0	0	2.6	0	5.2	0	0				
STANDBY	1.7	1.7	0.9	1.7	3.3	0	0	5.2	5.2	0	0	2.6	0	5.2	0	0				
REF NO. MODE	IC701																			
CD PLAY	0	0	0	0	0	0	0	0	0	0	3.4	3.4	0	3.4	0.8	0	0	0	0	0
STANDBY	0	0	0	0	0	0	0	0	0	0	3.4	3.4	0	3.4	0.7	0	0	0	0	0
REF NO. MODE	IC701																			
CD PLAY	0	0	0	0	0	3.4	0	3.4	3.4	0.7	3.4	0.7	3.4	0.7	3.4	0.7	3.4	3.4	0.7	3.4
STANDBY	0	0	0	0	0	3.4	0	3.4	3.4	0.5	3.4	0.7	3.4	0.7	3.4	0.7	3.4	3.4	0.7	3.4
REF NO. MODE	IC701																			
CD PLAY	0.8	3.4	0.8	3.4	0	0	0	0												
STANDBY	0.7	3.4	0.7	3.4	0	0	0	0												
REF NO. MODE	IC751																			
CD PLAY	3.4	1.5	3.4	1.5	1.5	0	1.5	1.6	3.4	1.4	1.7	0	1.4	3.4	3.3	3.4	3.4	3.4	3.4	0.1
STANDBY	3.4	1.5	3.4	1.5	1.5	0	1.5	1.6	3.4	1.4	1.7	0	1.4	3.4	3.3	3.4	3.4	3.4	3.4	0.1
REF NO. MODE	IC751																			
CD PLAY	0.4	0	0	0	0	0	3.4	0	0	0	0	0	0	0	0	0	3.4	1.6	3.3	0
STANDBY	0.4	0	0	0	0	0	3.4	0	0	0	0	0	0	0	0	0	3.4	1.6	3.3	0
REF NO. MODE	IC751																			
CD PLAY	0	1.3	3.4	1.4	1.4	0	1.4	1.7	3.4	1.4	1.7	0	1.4	0						
STANDBY	0	1.3	3.4	1.4	1.4	0	1.4	1.7	3.4	1.4	1.7	0	1.4	0						
REF NO. MODE	IC801																			
CD PLAY	0	0	0	0	0	3.4	0	0	0	0	0	0	3.4	0	0	0	0	0	3.4	1.6
STANDBY	0	0	0	0	0	3.4	0	0	0	0	0	0	3.4	0	0	0	0	0	3.4	1.6