

SCHEMATIC DIAGRAM - 4


— : +B SIGNAL LINE
 - - : -B SIGNAL LINE
 ▨ : PLAYBACK SIGNAL LINE
 ▩ : RECORD SIGNAL LINE
 ▧ : AUX SIGNAL LINE
 ▨ : RECORD SIGNAL LINE
 ▧ : MAIN SIGNAL LINE

TO **C**
 PANEL CIRCUIT
 (CP601) ON
 SCHEMATIC DIAGRAM-10

B MAIN CIRCUIT

TO **J**
 DECK
 CIRCUIT (CN1001) ON
 SCHEMATIC
 DIAGRAM-15

TO **H**
 CD LOADING
 CIRCUIT (CN1) ON
 SCHEMATIC
 DIAGRAM-11



TO **C**
PANEL CIRCUIT
(CP602) ON
SCHEMATIC DIAGRAM-10

— — : -B SIGNAL LINE




TO **A**
SERVO CIRCUIT

SCHEMATIC DIAGRAM - 6

— : +B SIGNAL LINE


B

MAIN CIRCUIT



— — : -B SIGNAL LINE

MAIN CIRCUIT



SCHEMATIC DIAGRAM - 8

B MAIN CIRCUIT

- : +B SIGNAL LINE
 - - : -B SIGNAL LINE
 ▨ : AUX SIGNAL LINE
 ▩ : CD SIGNAL LINE
 ▧ : MAIN SIGNAL LINE
 ▦ : PLAYBACK SIGNAL LINE
 ➡ : FM/AM SIGNAL LINE
 ▨ : RECORD SIGNAL LINE

