


**F**

 : PLAYBACK SIGNAL LINE



SCHEMATIC DIAGRAM - 23

F DECK CIRCUIT

— : +B SIGNAL LINE  
▨ : RECORD SIGNAL LINE  
▧ : PLAYBACK SIGNAL LINE

TO  
PANEL CIRCUIT  
(CP6803) ON  
SCHEMATIC  
DIAGRAM - 18

