











Item		FL Display	Key Operation
Mode Name	Description		Front Key
Cold Start	To active cold start upon next AC power up when reset start is execute the next time.		In Doctor Mode: 1. Press [DISPLAY/-DIMMER] button on remote control.
Volume Setting Check	To check the volume setting of a main unit.	 <p>Press [7]: VOL50 Press [8]: VOL35 Press [9]: VOL0 Press [PLAY/RADIO MODE]: VOL30</p> <p>↑ Volume</p>	In Doctor Mode: 1. Press [7],[8],[9], [PLAY MENU/RADIO MENU] button on remote control.
FL Display Check	To check the FL segment display All segment will light up while all LED blink at 0.5s, intervals.(if any)		In Doctor mode: 1. Press [1] button on remote control.
CD Open Check	To excute CD Open operation.		In Doctor mode: 1. Press [DEL] button on remote control.
BRS1C Reliability Test (Traverse)	<p>To determine CD Mechanism BRS1C Access Inner & Outer disc operation.</p> <p>In this mode,ensure the CD is in the main unit.</p> <p>Note: Refer to Section 6.3 Fig 2. for process flow.</p>	 <p>The counter will increment by one. When reach 9999 will change to 0000</p> <p>Cancellation Display</p> 	<p>In Doctor Mode: 1. Press [10]→[1]→[2] button on remote control.</p> <p>2. To cancel, press [0] on remote control.</p>
BRS1C Reliability Test (Combination)	<p>To determine CD Mechanism Unit (BRS1C) Open/Close & Access Inner & Outer Disc Operation.</p> <p>In this mode,ensure the CD is in the main unit.</p> <p>Note: Refer to Section 6.3 Fig 3. for process flow.</p>	 <p>The counter will increment by one. When reach 9999 will change to 0000</p> <p>Cancellation Display</p> 	<p>In Doctor Mode: 1. Press [10]→[1]→[5] button on remote control.</p> <p>2. To cancel, press [0] on remote control.</p>
BRS1C Reliability Test (Loading)	<p>To determine CD Mechanism Unit (BRS1C) Open/Close operation.</p> <p>In this mode, the tray will open & close.</p> <p>Note: Refer to Section 6.3 Fig 1 for process flow.</p>	 <p>The counter will increment by one. When reach 9999 will change to 0000</p> <p>Cancellation Display</p> 	<p>In Doctor Mode: 1. Press [10] →[2] →[1] button on remote control.</p> <p>2. To cancel, press [0] on remote control.</p>