



No.	Name
-----	------

- ① **Main power switch**
[MAIN POWER, OFF ON]
- ② **Main power indicator [MAIN POWER]**
Lights when [MAIN POWER] is on (), indicating the unit is in standby mode. Recharging begins if the rechargeable battery is connected and its voltage is low.
While this indicator is lit, pressing [POWER] switches the unit between on and standby.
- ③ **Power indicator [POWER]**
- ④ **Power “ STANDBY ON ” switch**
[POWER, STANDBY ON]
Press to switch the unit from on to standby mode and vice versa when [MAIN POWER] is on.
In standby mode, the unit is still consuming a small amount of power.
- ⑤ **Input selector**
- ⑥ **Voltage meter [BATTERY]**

No.	Name
-----	------

- ⑦ **Operation indicators [AC, DC, CHARGE]**
AC: Lights when operating on AC power.
DC: Lights when operating on the battery.
CHARGE: Lights when battery is charging.
- ⑧ **Volume control [VOL. (-dB)]**
- ⑨ **Panel open button [PUSH OPEN]**
Press to open the panel.
Close by hand.
- ⑩ **Headphone jack [MONITOR PHONES]**
- ⑪ **AC/DC operation button [OPERATION]**
- ⑫ **Voltage meter light button [METER LIGHT]**
- ⑬ **Mode selector [MODE]**
- ⑭ **Tape-monitor selector [TAPE MONITOR]**
- ⑮ **Balance control [BALANCE]**
- ⑯ **Balance control ON-OFF button**
[OFF ON]