





NOBLEX

PORTION TABLE		
	N/C	CONNECT
0705 (NTSC ONLY)	2-SYSTEM	NTSC
0706 (FNUZY)	ENABLE	DISABLE
0707 (STEREO)	STEREO	MONO









Mod.: 14TC628 / 20TC627


NOBLEX



NOBLEX



Mod.: 14TC628 / 20TC627





OPTIONAL

LDC	
CR11	
T401	
R41	
C40	
C41	
L40	
C42	
R805	
R820	
F822	



ONES THESE PARTS MARKED BY Δ ARE CRITICAL
FOR SAFETY USE ONES DESCRIBED ON PARTS
LIST ONLY.

LOC.	16 INCH	20 INCH	21 INCH	REMARK
C011	A34JL0WD1	A48JLL0TX02	A51BW9TX01	CRT
T401	FSA230275	FSA28023M	FSA28023M	FMT
R411	27K	24K	32K	ABL RESIDPOP
C404	8200P 1.8KV	8200P 1.8KV	7300P 1.8KV	C:
C411	0.38U	0.43U	0.38U	Cs
L403	NONE	NONE	TRW-300	H-WIDTH ADJ.
C412	470P 2KV	NONE	NONE	H-WIDTH ADJ.
R005	1.8K	1.8K	1K	SOUND OUTPUT(MONO)
R020	1K	1.8K	1.8K	B+ ADJUST
FUZZY	14 INCH: C061, R706, R733, C776 --->DELETE			

Mod.: 14TC628 / 20TC627