



INSTALLATION

CONNECT CENTER EXHAUST PIPE TO FRONT EXHAUST PIPE AND TAILPIPES

HINT:

- Install a new gasket to the exhaust pipe in the correct direction.
- Fit together the clamp protrusion and pipe hollow, and tighten the clamp bolt until A and B of the clamp are just touching.