


## REASSEMBLY

### INSTALL SUSPENSION SUPPORT AND COIL SPRING

- (a) Install the spring bumper to the suspension support.
- (b) Install the insulator to the suspension support.

**HINT:**

Match the bolt of the suspension support with the cut-off part of the insulator.



- (c) Using SST, compress coil spring.  
SST 09727-30021

**NOTICE:**

**Do not use an impact wrench. It will damage the SST.**

- (d) Install the coil spring to the shock absorber.

**HINT:**

Fit the lower end of the coil spring into the gap of the spring seat of the shock absorber.

- (e) Install the suspension support to the rod and temporarily tighten a new nut.

- (f) Rotate the suspension support so that the rod and one of the bolts on suspension support are aligned with the lower bushing.

- (g) Remove the SST.

**HINT:**

After removing the SST, again check the direction of the suspension support.

