DEFOGGER SYSTEM

LOCATION

BE0C7–01

Engine Room Junction Block
- MIR–HTR Fuse
- Defogger Relay

A/C Control Panel Assembly
- A/C Control Panel
- A/C Amplifier

Instrument Panel
Junction Block
- HEATER Fuse

Ignition Switch

RH Mirror
- Mirror Defogger

Rear Window Glass
- Window Defogger

LH Mirror
- Mirror Defogger

I03407