



DISPOSAL

1. FULLY EXTEND SHOCK ABSORBER ROD
2. DRILL HOLE TO REMOVE GAS FROM CYLINDER

Using a drill, make a hole in the cylinder as shown to bleed the gas inside.

CAUTION:

The gas coming out is harmless, but be careful of chips which may fly up when drilling.