


# AIR CONDITIONING CONTROL ASSEMBLY (Except Electrical Multi Vision)

AC0PJ-01

## REMOVAL


### 1. REMOVE THESE PARTS :

- (a) Cluster finish panel
- (b) No.2 register (See page [BO-83](#))



### 2. REMOVE A/C CONTROL ASSEMBLY

- (a) Remove the 4 bolts and pull out A/C control assembly, then disconnect the connectors.



- (b) Remove the 2 screws and A/C control assembly from the radio.