



INSTALLATION

1. **INSTALL CAMSHAFT POSITION SENSOR**
Torque: 7.5 N·m (80 kgf·cm, 66 in.-lbf)
2. **CONNECT CAMSHAFT POSITION SENSOR CONNECTOR**
3. **INSTALL NO.3 TIMING BELT COVER**
(See page [EM-22](#))
4. **CONNECT RADIATOR HOSE**
5. **INSTALL AIR CLEANER INLET**
6. **INSTALL BATTERY CLAMP COVER**
7. **INSTALL V-BANK COVER**
8. **FILL ENGINE COOLANT** (See page [CO-2](#))
9. **CHECK ENGINE COOLANT FOR LEAKS**
10. **CHECK IGNITION TIMING** (See page [EM-9](#))