


## INSTALLATION

### 1. CLEAN MOULDING MOUNTING SURFACE

Wipe off stains with cleaner.



### 2. HEAT BODY MOUNTING SURFACE

Using a heat light, heat the body mounting surface to 40–60°C (104–140°F).

#### NOTICE:

When the moulding is installed, the temperature of the mounting surface should be 20°C (68°F) or higher.

### 3. HEAT MOULDING

Using a heat light, heat the moulding to 20–30°C (68–86°F).

#### NOTICE:

Do not heat moulding excessively.

The temperature should not be higher than 80°C (176°F).

### 4. INSTALL MOULDING

- Align the bolts and the moulding with the body holes, and push the moulding to the body.
- Install the nuts.

#### NOTICE:

- Be sure that the body and moulding are heated to the proper temperature.
- Do not depress the adhesive-coated parts excessively, just hold them down with your thumb.
- After installation, do not wash the vehicle for 24 hours.

