



INSTRUMENT PANEL COMPONENTS


B00P4-03





H01672









BODY - INSTRUMENT PANEL



Z16969

HINT:

Screw shapes and sizes are indicated in the table below. The codes (A – K) correspond to those indicated on the previous page.

						mm (in.)		
	Shape	Size		Shape	Size		Shape	Size
Ⓐ		∅ = 8 (0.31) L = 20 (0.79)	Ⓑ		∅ = 6 (0.24) L = 18 (0.71)	Ⓒ		∅ = 6 (0.24) L = 20 (0.79)
Ⓓ		∅ = 6 (0.24) L = 20 (0.79)	Ⓔ		∅ = 5 (0.20) L = 14 (0.55)	Ⓕ		∅ = 8 (0.31)
Ⓖ		∅ = 6 (0.24)	Ⓖ		∅ = 6 (0.24)	Ⓖ		∅ = 5.22 (0.2055) L = 16 (0.63)
Ⓙ		∅ = 8 (0.31) L = 18 (0.71)	Ⓚ		∅ = 6 (0.24) L = 25 (0.98)			

H03596