


PARKING BRAKE PEDAL ON-VEHICLE INSPECTION

BR000-01

1. CHECK PARKING BRAKE PEDAL TRAVEL

Depress the parking brake pedal all the way and count the number of clicks.

**Parking brake pedal travel at 294 N (30 kgf, 66.1 lbf):
5-7 clicks**



2. IF NECESSARY, ADJUST PARKING BRAKE

- (a) Adjust the parking brake shoe clearance.
- (b) Loosen the adjuster lock nut and adjuster until the parking brake pedal travel becomes correct.

HINT:

If the adjustment cannot be made within the range of travel of the adjuster, remove the propeller shaft and make an adjustment at the pull rod.