


















# ENGINE MECHANICAL

## SST (Special Service Tools)

PP0NB-02

	09201-01055	Valve Guide Bushing Remover & Replacer 5.5	
	09201-41020	Valve Stem Oil Seal Replacer	
	09202-70020	Valve Spring Compressor	
	(09202-00010)	Attachment	
	09213-70010	Crankshaft Pulley Holding Tool	
	(90105-08076)	Bolt	
	09222-30010	Connecting Rod Bushing Remover & Replacer	
	09223-46011	Crankshaft Front Oil Seal Replacer	Camshaft oil seal Crankshaft pulley Crankshaft timing pulley
	09223-56010	Crankshaft Rear Oil Seal Replacer	
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	Crankshaft front oil seal
	09330-00021	Companion Flange Holding Tool	Crankshaft pulley

	<p>09843-18020 Diagnosis Check Wire</p>	
	<p>09950-50012 Puller C Set</p>	
	<p>(09951-05010) Hanger 150</p>	<p>Crankshaft pulley Crankshaft timing pulley</p>
	<p>(09952-05010) Slide Arm</p>	<p>Crankshaft pulley Crankshaft timing pulley</p>
	<p>(09953-05010) Center Bolt 100</p>	<p>Crankshaft pulley Crankshaft timing pulley</p>
	<p>(09953-05020) Center Bolt 150</p>	<p>Crankshaft pulley Crankshaft timing pulley</p>
	<p>(09954-05010) Claw No.1</p>	<p>Crankshaft timing pulley</p>
	<p>(09954-05020) Claw No.2</p>	<p>Crankshaft pulley</p>
	<p>09950-60010 Replacer Set</p>	
	<p>(09951-00240) Replacer 24</p>	<p>Spark plug tube</p>
	<p>(09951-00460) Replacer 46</p>	<p>Spark plug tube</p>
	<p>(09952-06010) Adapter</p>	<p>Spark plug tube</p>
	<p>09950-70010 Handle Set</p>	

PREPARATION - ENGINE MECHANICAL

	(09951-07100) Handle 100	Spark plug tube Valve guide bushing
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	Camshaft sub-gear
	(09963-00350) Pin 3.5	Camshaft
	(09963-00500) Pin 5	Camshaft sub-gear