

INSTALLATION

Installation is in the reverse order of removal (See page [BR-13](#)).

1. BEFORE INSTALLATION, ADJUST LENGTH OF BRAKE BOOSTER PUSH ROD (See page [BR-21](#))
2. AFTER INSTALLATION, FILL BRAKE FLUID AND BLEED BRAKE SYSTEM (See page [BR-4](#)), CHECK FOR FLUID LEAKAGE
3. CHECK AND ADJUST BRAKE PEDAL (See page [BR-6](#))