


# AIR CONDITIONING CONTROL ASSEMBLY (Electrical Multi Vision) REMOVAL

AC0PG-01

## 1. REMOVE THESE PARTS :

- (a) Cluster finish panel
- (b) No.2 register  
(See page [BO-83](#))



## 2. REMOVE A/C CONTROL ASSEMBLY

- (a) Remove the 4 bolts and pull out the A/C control assembly, then disconnect the connectors.

- (b) Remove the 8 bolts, 2 screws and 2 brackets.
- (c) Separate the A/C control assembly, radio and A/C amplifier.

