



FILE NO.

## SERVICE MANUAL Colour Television

Model No. CP21G1(A)

(Australia)

Service Ref. No. CP21G1-50



### Specifications

Power Source . . . . . AC220-240V, 50Hz/60Hz.  
 Colour System . . . . . PAL (AV input: PAL/NTSC4.43/NTSC/PAL-60Hz)  
 Television System . . . . . B/G  
 Channel Coverage . . . . .Australia  
     VHF: 0-11, 5A  
     UHF: 28-69  
     CATV: S1-S41, X, Y, Z, Z+1, Z+2  
 New Zealand  
     VHF: 1-11  
     UHF: 21-69  
     CATV: S1-S41, X, Y, Z, Z+1, Z+2  
 Video IF . . . . . 38.0MHz  
 Aerial Input Impedance . . 75Ω  
 Ext. Terminals  
     Video inputs: Phono jack × 2 (1Vp - p, 75Ω)  
     Audio inputs: Phono jack × 2 (436mVrms, more than 40KΩ)  
 Sound Output (RMS) . . . . 2 W  
 Speaker . . . . . Diameter 8 cm × 2 pcs.  
 Dimensions . . . . . 502 (W) × 461.6 (H) × 493.3 (D)mm  
 Weight . . . . . approx. 21.5 Kg

*Specifications subject to change without notice.*

Product Code: 111367016

Original Version

Chassis Series: AC5-G

Give complete "SERVICE REF. NO." for parts order or servicing. It is shown on the rating plate at the cabinet back of the unit.

This T.V. receiver will not work properly in foreign countries where the television transmission system and power source differ from the design specifications. Refer to the specification table.

# Contents

---

Safety Notice . . . . .	2
Chassis Block Diagram . . . . .	3-4
IC Block Diagrams . . . . .	5-7
Service Information . . . . .	7
Service Adjustments with replacing Memory IC (IC802) . . . . .	8-11
Service Mode Adjustments . . . . .	12-13
Service Adjustments . . . . .	14
Special Function . . . . .	15
Purity and Convergence Adjustment . . . . .	16
Cabinet Parts List . . . . .	17
Chassis Electrical Parts List . . . . .	18-23

# Safety Notice

---

## SAFETY PRECAUTIONS

- 1: An isolation transformer should be connected in the power line between the receiver and the AC line when a service is performed on the primary of the converter transformer of the set.

2: Comply with all caution and safety-related notes provided on the cabinet back, inside the cabinet, on the chassis or the picture tube.
- 3: When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as, control knobs, adjustment covers or shields, barriers, isolation resistor-capacitor networks etc.. Before returning any television to the customer, the service technician must be sure that it is completely safe to operate without danger of electrical shock.

## X-RADIATION PRECAUTION

The primary source of X-RADIATION in television receiver is the picture tube. The picture tube is specially constructed to limit X-RADIATION emissions. For continued X-RADIATION protection, the replacement tube must be the same type as the original including suffix letter. Excessive high voltage may produce potentially hazardous X - RADIATION. To avoid such hazards, the high voltage must be maintained within specified limit. Refer to this service manual, high voltage adjustment for specific high voltage limit. If high voltage exceeds specified limits, take necessary corrective action. Carefully follow the instructions for + B1 volt power supply adjustment, and high voltage check to maintain the high voltage within the specified limits.


## PRODUCT SAFETY NOTICE

Product safety should be considered when a component replacement is made in any area of a receiver. Components indicated by mark ⚠ in the parts list and the schematic diagram designate components in which safety can be of special significance. It is particularly recommended that only parts designated on the parts list in this manual be used for component replacement designated by mark ⚠ . No deviations from resistance wattage or voltage ratings may be made for replacement items designated by mark ⚠ .

# Chassis Block Diagrams

## MAIN SIGNAL PROCESSING CIRCUIT


\* Teletext decoder and SECAM decoder are not equipped.



\* Not equipped


# Chassis Block Diagrams

## SYSTEM CONTROL




# IC Block Diagrams

IC201 < IF/Video/Chroma/Def. > LA76818A




# IC Block Diagrams

IC201 <IF System Block Diagram> LA76818A




# IC Block Diagrams

## IC501 < Vertical Output > LA78040/LA78040N



## IC001 < Audio AMP.> LA4266



## Service Information

### ■ Protection Circuit

This TV set has a built-in power supply protection circuit.

It is provided to protect the TV set in case of a power supply circuit malfunctions. When something abnormality occurs during TV reception, the TV set goes to the stand-by mode.

When an abnormality occurs during TV reception, it causes pin 27 of the CPU to go continually Low (less than 0.75V) for about one second. The CPU detects that this has occurred and outputs the signal from pin 31 to switch off the power supply lines.

### Releasing the protective circuit and restoring power supply



To release the protective circuit and restore power supply, turn the power to the TV set OFF and then ON again via either the main power switch or the ON-OFF button on the remote control. This will work only if the power supply trouble was temporary. If there is permanent trouble such as a damaged circuit, power cannot be restored and the circuit will have to be repaired.

# Service Adjustments with Replacing Memory IC(IC802)



Note: The CPU (IC801) and memory IC (IC802) store the service adjustments data and controls data for each circuit. When the Memory IC (IC802) is replaced, some of the service adjustments should be readjusted to obtain the best performance. The necessary service adjustments are carried out by using the RC handset. Please set up the TV set with following steps [1] to [2].

## [1] Initializing Procedure

1. Put a new memory IC.
2. Turn on the TV set.
3. Press and hold the **TV/AV Selector** on the TV set for more than 2 seconds. The following picture appears on the screen.



4. Press the **PROGRAMME UP** on the TV set while the above On-Screen Display is still on the screen. The following picture appears on the screen.



This completes the initialization of memory IC.

Following shows the initialized contents of memory data by this procedure.

- |                     |                |
|---------------------|----------------|
| - Plug & Play       | : No executed  |
| - Inhibit Data      | : Cancelled    |
| - Ch Skip Data      | : Cancelled    |
| - Sound Volume Data | : 10/63 steps. |
| - Volume Lock       | : OFF          |
| - Tuning Lock       | : OFF          |
| - Music Mode        | : OFF          |
| - AV Start          | : OFF          |
| - Colour System     | : AUTO         |

## [2] Required Service Adjustments

Readjust the following service adjustments.

<u>Adjustments</u>	<u>Service Mode No. &amp; Item</u>
RF AGC	Item 01, RF AGC
Horizontal centre	Item 02, H-PHA
Vertical size	Item 04, V-SIZ
Vertical-S correction	Item 05, V-SCO
Vertical linearity	Item 06, V-LIN
Gray scale	Item 14-17, 19-21

Further adjustment please refer to page 12 and 13.



# Service Adjustments with Replacing Memory IC(IC802)

Following table shows the initial values which have been stored in the CPU ROM, and items for the service adjustments.

## Service mode adjustments table in CPU ROM

No.	ITEM	DATA RANGE	INITIAL SETUP DATA	DESCRIPTION
01	RFAGC	0~63	31	RF AGC Adj.
02	H-PHA	0~31	9	H-Phase (H-Centering) Adj. (50Hz)
03	V-POS	0~63	40	V-Position (V-Centering) Adj. (50Hz)Fixed.
04	V-SIZ	0~127	65	V-Size Adj. (50Hz)
05	V-SCO	0~31	12	V-S Correction (50Hz)
06	V-LIN	0~31	20	V-Linearity Adj. (50Hz)
07	H-P60	-16~+15	+5	H-PHASE Adj. (60Hz)
08	V-S60	-64~+32	0	V-Size Adj. (60Hz)
09	OSDHP	0~255	26	OSD H-Position Adj.
10	OSDC	0~127	60	OSD Contrast Adj.
11	V-SCP	0~7	7	Correction of the V-size accompanying brightness change.
12	H-SCP	0~7	7	Correction of the H-size accompanying brightness change.
13	SBIAS	0~127	105	Sub Bias Adj. (Do not change)
14	RBIAS	0~255	0	Red Bias Adj.
15	GBIAS	0~255	0	Green Bias Adj.
16	BBIAS	0~255	0	Blue Bias Adj.
17	RDRIV	0~127	64	Red Drive Adj.
18	GDRIV	0~15	8	Green Drive Adj.
19	BDRIV	00~127	64	Blue Drive Adj.
20	1-LINE APPEAR			White Balance Adj.
21	DRV			White Balance Adj.
22	B-YD	0~15	8	B-Y DC level Adj.
23	R-YD	0~15	8	R-Y DC level Adj.
24	B-YDN	-16~+15	0	NTSC B-Y DC level Adj.
25	R-YDN	-16~+15	0	NTSC R-Y DC level Adj.
26	SBDC	-16~+15	-4	SECAM B-Y DC level Adj.
27	SRDC	-16~+15	-1	SECAM R-Y DC level Adj.
28	G-YA	0,1	0	G-Y angle Adj.
29	RBGB	0~15	8	R-Y, B-Y Gain Balance Adj. (Do not change.)
30	RBAG	0~15	8	R-Y, B-Y Angle Adj. (Do not change.)
31	G-YAN	0,1	0	NTSC G-Y Angle Adj.
32	RBGBN	-16~+15	0	NTSC R-Y, B-Y Gain Balance Adj.
33	RBAGN	-16~+15	0	NTSC G-Y, B-Y Angle Adj.
34	COGV	0~3	0	Coring Gain Adj.
35	BLKS	0~3	3	Setting of Black stretch start.
36	BLKG	0~3	3	Setting of Black stretch gain.
37	BRTA	0,1	0	On and off of ABL.
38	BRST	0,1	0	Setting of ABL.
39	BRTH	0~7	0	Setting of ABL.
40	WPL	0~3	2	White peak limiter.
41	YGAM	0~3	0	Y Gamma setting.
42	PORW	0,1	0	Switching of Pre-shoot and Over shoot in AV mode.

No.	ITEM	DATA RANGE	INITIAL SETUP DATA	DESCRIPTION
43	PORS	0~3	2	Pre-shoot/Over shoot Adj. in AV mode.
44	RFCO	0~3	0	RF Coring Gain Adj.
45	PORWN	0,1	0	Switching of RF Pre-shoot and Over shoot.
46	PORSN	0~3	0	RF Pre-shoot/Over shoot Adj.
47	TINT	-16~+15	0	RF Tint Adj.
48	TINT443	-16~+15	-12	NTSC 4.43 Tint Adj.
49	SHRF	-32~+31	0	RF Sharpness Adj.
50	TEXTC	-128~+127	0	OSD TEXT Contrast.
51	VOLUM	0~255	127	Volume Control Adj.
52	DEEM	0~1	0	De emphasis TC.
53	VIFSW	0~3	0	VIF System Switch.
54	SIFSW	0~3	1	SIF System Switch.
55	V-LVL	0~7	4	Video Level Adj.
56	FMLVL	0~31	16	FM Level Adj.
57	IFOM-S	0,1	0	Over Modulation Switch
58	IFMN-S	0,1	1	Audio Monitor Switch
59	IFTRAPS	0,1	1	SIF Trap Switch ON/OFF
60	IFMLVL	0~255	136	Video Level & Modulation
61	TRAP-T	0~7	4	Trap Test
62	H-FRQ	0~63	34	Horizontal Frequency
63	FBTS	0,1	0	FBT Blanking Switch
64	COOP	0~7	7	Color Killer Option
65	HBLKL	0~7	7	H-Blanking Control. (Left)
66	HBLKR	0~7	3	H-Blanking Control. (Right)
67	AFCRF	0,1	0	RF AFC gain & Gate Adj.
68	VSRF	0,1	0	RF Vert. Sync. Separation Adj.
69	CDMRF	0~7	0	RF Vert. Count-Down Circuit Adj.
70	AFCAV	0,1	1	AV AFC Gain & Gate Adj.
71	VSUAV	0,1	0	AV Vert Sync. Separation Adj.
72	CDMAV	0~7	0	AV Vert Count-Down Circuit Adj.
73	HLVDRF	0,1	1	H Lock, V Detect RF
74	HLVDAV	0,1	1	H Lock, V Detect AV
75	VCO-SW	0,1	0	C-VCO Adj. Switch
76	VCO-ADJ	0~3	3	C-VCO Adj.
77	CROSS-BW	0~3	0	Output Pattern Picture
78	AVNCON	0~127	64	AV Blue Back Signal Contrast
79	AVNBRI	0~127	64	AV Blue Back Signal Brightness
80	POMT	0~127	25	Power Mute Time Adj.
81	CHMT	0~31	10	Channel Change Mute time Agj.
82	SYST	0~15	5	The number of times that a colour system AUTO is judged.
83	S-STE	0~3	0	Stereo/Mono Option. 0=MONO, 1=SIMPLE AV STEREO, 2,3=AV STEREO
84	VOLTBL	0~1	1	Volume Table
85	MPP	0,1	0	Multi Personal Preference function on/off 0=without M.P.P., 1=with M.P.P.

# Service Adjustments with Replacing Memory IC(IC802)

No.	ITEM	DATA RANGE	INITIAL SETUP DATA	DESCRIPTION
86	TUNER	0,1	0	Tuner Option
87	AV123	0~3	0	AV1/AV2/AV3 Option, 0=AV only, 1=AV1, AV2, 2~3=AV1, AV2,AV3
88	OPT POS	0,1	1	Programme number Option, Position No. Option, 0=100 pos., 1=256 pos.
89	GAME	0,1	1	GAME Option, 0=without GAE, 1=with GAME
90	LANGUAGE	0,1	1	Language Option, 0=without Language, 1=with Language
91	OPT COL	0~7	2	Colour System Option, 0~1=PAL only, 2=VMT, 3=China/Indonesia, 4=3 System, 5~7=Multi
92	OPT SIF	0~7	0	SIF System Option
93	OPT BASS	0~3	0	Bass Expander Option, 0=without BASS, 1~2=BASS EXPANDER, 3=WOOFER
94	OPT SURR	0,1	0	Surround Option, 0=without SURROUND, 1=with SURROUND
95	SUB-BT	0,1,2	0	Audio IC (NJW1142)Sub Bass Treble adj.
96	A-AGC	0,1,2	0	Audio IC (NJW1142) AGC adj.
300	R00	0~255	154	ROM Correction
301	R01	0~255	242	ROM Correction
302	R02	0~255	166	ROM Correction
303	R03	0~255	246	ROM Correction
304	R04	0~255	3	ROM Correction
305	R05	0~255	0	ROM Correction
306	R06	0~255	0	ROM Correction
307	R07	0~255	0	ROM Correction
308	R08	0~255	2	ROM Correction
309	R09	0~255	229	ROM Correction
310	R10	0~255	144	ROM Correction
311	R11	0~255	13	ROM Correction
312	R12	0~255	239	ROM Correction
313	R13	0~255	141	ROM Correction
314	R14	0~255	238	ROM Correction
315	R15	0~255	141	ROM Correction
316	R16	0~255	237	ROM Correction
317	R17	0~255	141	ROM Correction
318	R18	0~255	236	ROM Correction
319	R19	0~255	141	ROM Correction
320	R20	0~255	235	ROM Correction
321	R21	0~255	141	ROM Correction
322	R22	0~255	33	ROM Correction
323	R23	0~255	155	ROM Correction
324	R24	0~255	6	ROM Correction
325	R25	0~255	33	ROM Correction


No.	ITEM	DATA RANGE	INITIAL SETUP DATA	DESCRIPTION
326	R26	0~255	154	ROM Correction
327	R27	0~255	246	ROM Correction
328	R28	0~255	0	ROM Correction
329	R29	0~255	0	ROM Correction
330	R30	0~255	0	ROM Correction
331	R31	0~255	0	ROM Correction
332	R32	0~255	0	ROM Correction
333	R33	0~255	0	ROM Correction
334	R34	0~255	0	ROM Correction
335	R35	0~255	0	ROM Correction
336	R36	0~255	0	ROM Correction
337	R37	0~255	0	ROM Correction
338	R38	0~255	0	ROM Correction
339	R39	0~255	0	ROM Correction
340	R40	0~255	107	ROM Correction
341	R41	0~255	127	ROM Correction
342	R42	0~255	7	ROM Correction
343	R43	0~255	3	ROM Correction
344	R44	0~255	234	ROM Correction
345	R45	0~255	144	ROM Correction
346	R46	0~255	3	ROM Correction
347	R47	0~255	33	ROM Correction
348	R48	0~255	166	ROM Correction
349	R49	0~255	249	ROM Correction
350	R50	0~255	33	ROM Correction
351	R51	0~255	167	ROM Correction
352	R52	0~255	34	ROM Correction
353	R53	0~255	0	ROM Correction
354	R54	0~255	0	ROM Correction
355	R55	0~255	0	ROM Correction
366	R12	0~255	0	ROM Correction
367	R13	0~255	0	ROM Correction
368	R68	0~255	0	ROM Correction
369	R69	0~255	0	ROM Correction
370	R70	0~255	0	ROM Correction
371	R71	0~255	0	ROM Correction
372	R72	0~255	160	ROM Correction

**Notes:** The initial value that the CPU writes down the CPU ROM data to the memory when replaced the memory IC. TV set may not operate correctly with this initial value. It is required to set up the fine adjustment for service adjustments described in the above.


# Service Adjustments with Replacing Memory IC(IC802)

## [Entering to Service Mode]



1. Press and hold the **MENU** button on the Remote Control and press the **VOLUME (+)** button on the TV set.  
Following setting items appears on the screen.



Display for [RF AGC] RF AGC adjustment




2. Select item by pressing the **TIMER** (Item No. UP) or **SOUND MUTE** (Item No. DOWN) button on the remote control handset.




### Example


Display for [V-SCO] V-S Correction adjustment



Display for [DRV] White balance adjustment



3. Adjust data value by pressing the **VOLUME +** or **VOLUME -** button on the remote control handset.



To return to normal TV mode, press the **MENU** button on the TV set or the remote control handset.

# Service Mode Adjustments

Following adjustments should be carried out when the memory IC is replaced. How to enter the service mode and adjust values, please refer to "Entering to Service mode" on page 11.


## Item 01 [RF AGC] AGC

NOTE: Do not attempt this adjustment with weak signal.

- (1) Tune the receiver to most clearest (or strongest) VHF station in your area. Set the brightness and contrast controls to maximum. Set the colour control to minimum.
- (2) Select [RF AGC] in the service mode.
- (3) Change value until the snow noise just disappears.
- (4) Exit from service mode.


## Item 02 [H-PHA] HORIZONTAL CENTRE

- (1) Receive a monochrome circular pattern.
- (2) Set the brightness and contrast to normal.
- (3) Select [H-PHA] in the service mode.
- (4) Change value to be optimum horizontal centre position.
- (5) Exit from service mode.




## Item 04 [V-SIZ] VERTICAL SIZE

- (1) Receive a monochrome circular pattern.
- (2) Set the brightness and contrast to maximum.
- (3) Select [V-SIZ] in the service mode.
- (4) Change value to be optimum vertical size.
- (5) Exit from service mode.




## Item 05 [V-SCO] V-S CORRECTION

- (1) Receive a crosshatch pattern.
- (2) Select a picture mode of NATURAL by pressing the PICTURE MODE button.
- (3) Select [V-SCO] in the service mode.
- (4) Adjust Vertical S-letter Correction so that the difference of "c", "d" and "e" becomes less than 2 mm by pressing the VOLUME + or - button.
- (5) Confirm Vertical Linearity and adjust Vertical Size.
- (6) Exit from service mode.



## Item 06 [V-LIN] VERTICAL LINEARITY

- (1) Receive a crosshatch pattern.
- (2) Select a picture mode of NATURAL by pressing the PICTURE MODE button.
- (3) Select [V-LIN] in the service mode.
- (4) Adjust Vertical Linearity so that the difference of "a" and "b" becomes less than 3mm by pressing VOLUME + or - button.
- (5) Exit from service mode.




# Service Mode Adjustments

## Items 14-17, 19-21 GREY SCALE


- (1) Receive the monochrome circular pattern.
- (2) Set the brightness and colour to normal, contrast to maximum.
- (3) Enter to the service mode.
- (4) Set each value of Item-14 **RBIAS**, 15 **GBIAS**, 16 **BBIAS**, 17 **RDRIV** and 19 **BDRIV** mode to 64.
- (5) Select Item-20 mode to be one horizontal scanning line and turn the screen volume on the FBT to obtain just visible one coloured line.
- (6) Press the **1 (Red Bias -)**, **2 (Red Bias +)**, **5 (Green Bias -)**, **6 (Green Bias +)**, **9 (Blue Bias -)** or **0 (Blue Bias +)** button to adjust the brightness of each colour until a dim white line produced. Please see the control button allocations in this mode.
- (7) Select Item-21 **DRV** mode to enter the white balance adjusting mode.
- (8) Press the **3 (Red Drive -)**, **4 (Red Drive +)**, **-/-- (Blue Drive -)** or **RECALL (Blue Drive +)** button alternately to produce normal black and white picture.
- (9) Exit from the service mode.
- (10) Check for proper grey scale tracking at all brightness levels.

NOTE: If the grey scale adjustment is made after picture tube replacement, check the high voltage.



Press the MENU button to exit from service mode.

## MAIN BOARD



SCREEN VR  
(Under side)


# Service Adjustments

Following adjustments are not required to readjust when replacing the memory IC.

## B-VOLTAGE SUPPLY CHECKING

- (1) Connect DC meter to TP-B and the ground.
- (2) Tune the receiver to an active channel and synchronized picture. Select NATURAL picture mode by pressing the **PICTURE MODE** button on the remote control.
- (3) Adjust B-voltage to be  $130 \pm 1V$  DC by using VR631.

### MAIN BOARD



B-Voltage Supply Adjustment

## HIGH VOLTAGE CHECK

**Note:** +B (+130V) Voltage Check and Grayscale Adjustment must be completed before attempting High Voltage Check.

- (1) Connect high voltage voltmeter negative lead to ground, and connect + lead to anode of picture tube.
- (2) Tune receiver to an active channel and confirm TV is operating properly.
- (3) Maximize the beam current by adjusting the contrast and brightness controls to maximum. Confirm high voltage is within 24.0 KV and 26.5 KV at maximum beam current.
- (4) Eliminate the beam current by adjusting the contrast and brightness controls to minimum. Confirm high voltage does not exceed 28.0 KV at zero beam current.


If reading is not within range, check horizontal circuit.

No high-voltage adjustment is provided on this chassis.

## FOCUS ADJUSTMENT

- (1) Receive the monochrome circular pattern.
- (2) Set the brightness to normal and contrast to maximum.
- (3) Adjust the focus control on the F.B.T. for the best focus on the screen centre.

### MAIN BOARD



Focus VR  
(Upper side)

# Special Function

The following special functions can be set up on this TV set.

## (1) Volume Lock setting

With this function, a maximum sound volume limit can be set at any level.




## (2) Tuning Lock setting

Once TUNING LOCK is switched on, further channel tuning (Pre-set) is not possible. The Channel Swapping function also is not possible.



## (3) Music Mode setting

When Music Mode is ON, Programme position from "91" to "99" and "0" are set Music Mode. Only sound is provided and any picture is not on the screen under Music Mode.



## (4) AV Start setting


Set AV-START to ON and every time the TV set is switched on, AV position will be the initial programme position.




## How to set the special function:

**Note:** When making the VOLUME LOCK setting, set the desired maximum sound volume by pressing the **VOLUME +** or **-** button before entering Special Function setting mode.


- 1 To enter into the special function setting mode, press and hold the **MENU** button of the remote control, then press the **PROGRAMME DOWN** button on the TV set.




- 2 Select an item of the special functions by pressing the **PROGRAMME UP** or **DOWN** button on the remote control or the TV set.



- 3 Set the selected special function "ON" by pressing the **VOLUME +** or **-** button. To cancel, set to "OFF".



- 4 Press the **MENU** button of the remote control to return to the normal TV mode.





# Purity and Convergence Adjustment

**CAUTION:** The Convergence and Purity adjustments have been made at the factory. Readjustment should be made only after picture tube or deflection yoke replacement, following the steps below:

## PURITY ADJUSTMENT

1. Demagnetize the picture tube and receiver using an external degaussing coil. When replacing picture tube or deflection yoke, mount deflection yoke and purity-convergence magnets assembly properly, see figures 1 and 4.
2. Turn Red and Blue guns off and provide only Green raster. Rotate Screen control to fully counterclockwise. Rotate Red and Blue Bias controls fully counterclockwise. Slowly rotate Green Bias control clockwise to produce Green raster.
3. Loosen the screw holding the Deflection Yoke and remove the 3 Rubber Wedges, and slide the Deflection Yoke fully forward.
4. Rotate and spread the Tabs of the two Purity Magnets to centre the vertical green belt in the picture screen. The Purity Magnets are also adjusted to obtain vertical centring of the raster.
5. Slowly slide the Deflection Yoke backward until a uniform green screen is obtained.
6. Check the purity of the red and blue screens for uniformity, turn off other colours to check this (use bias controls). Readjust the yoke position if necessary until all screens are pure.
7. Adjust each Bias control and screen control to obtain white raster. Refer to Gray Scale Adjustment. If part of the picture screen is coloured, adjust the Deflection Yoke position forward or backward slightly.




Figure 1. Purity and Convergence Magnets




Figure 4. Deflection Yoke Movement




Figure 5. Adjusting Magnet

8. Tighten the mounting screw of the Deflection Yoke. Adjust Convergence next.

## CENTRE CONVERGENCE ADJUSTMENT

1. Use a dot crosshatch pattern signal.
2. Turn Red and Blue guns on and turn off Green gun. Adjust the angle between the Tabs of the Four Pole Magnet 1 and 2, and superimpose the Red and Blue vertical lines in the centre area of the picture screen. Refer to figure 2.
3. Keeping the mutual angle of the Tabs of the Four Pole Magnet turn them together to superimpose the Blue and Red horizontal lines in the centre area of the picture screen. Refer to figure 2.
4. Turn Green gun on and adjust Six Pole Magnet 3 and 4 that the Green line superimposed on the Red/Blue lines. This is the same procedure used in steps 2 and 3. Refer to figure 3.

## OUTER AREA CONVERGENCE ADJUSTMENT

Slightly loosen the screw holding the Deflection Yoke. Adjust the Deflection Yoke to converge the detail in the outer area (left side and right side) of the picture screen by orbital movement of the front of the Yoke, then secure the Deflection Yoke in appropriate position by putting the wedges as illustrated. Tighten screw holding the Deflection Yoke.

Adjust tabs angle to superimpose blue and red vertical line.




Figure- 2 BLUE AND RED LINE MOVEMENT

Adjust tabs angle to superimpose red/blue and green vertical line.





Figure- 3 BLUE/RED AND GREEN MOVEMENT



# Cabinet Parts List

Note: Parts order must contain Service Ref. No., Part No., and descriptions.



Key No.	Part No.	Description	Key No.	Part No.	Description
1	610 304 8406	BUTTON POWER-C4EA			
2	610 304 8468	DEC. IND-C4EA			
3	610 304 8413	BUTTON UNITED-C4EA			
4	610 304 8437	CABINET FRONT-C4MA			
5	645 040 4672	BADGE,SANYO*43.5X10L43.5			
	645 041 7269	BADGE,SANYO*43.5X10L43.5			
6	610 306 8848	CABINET BACK-C4MY			
7	610 311 4682	LABEL RATING-C4MV			
8	645 054 3579	ASSY,REMOCON JXMYA			
9	610 300 5102	RC-BATTERY LID-JXMYA			
	610 311 2404	INSTRUCTION MANUAL-C4EV			



# Chassis Electrical Parts List

C4MV

Product safety should be considered when a component replacement is made in any area of a receiver. Components indicated by a  $\Delta$  mark in this parts list and the circuit diagram show components whose value have special significance to product safety. It is particularly recommended that only parts specified on the following parts list be used for components replacement pointed out by the mark.

Note: Parts order must contain Service Ref. No., Part No., and descriptions. The main PCB unit will be supplied without tuner and flyback transformer. They should be ordered separately.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
<div>NOTES:</div> <div>Read description in the Capacitor and Resistor as follows:</div> <div>CAPACITOR</div> <div>CERAMIC 100P K 50V</div> <div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div>&lt;/</div></div></div>					

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description			
Q685	405 011 8500	TR 2SC1740S-R	IC801	409 320 5700	IC UPC78M05AHF			
	405 011 8609	TR 2SC1740S-S		410 486 2007	IC LC863448W-XXXX-TLM			
	405 012 2002	TR 2SC1815-GR		IC802	410 495 8007	IC AT24C16A-10PI-2.7		
	405 012 2101	TR 2SC1815-O		409 459 4506	IC 24LC16B/P			
	405 012 2309	TR 2SC1815-Y	CAPACITOR					
	405 020 7501	TR 2SC945A-PA						
	405 020 7709	TR 2SC945A-QA		C003	404 089 7200	ELECT	100U M	25V
	405 020 7907	TR 2SC945A-RA			403 044 9501	ELECT	100U M	25V
	405 014 4509	TR 2SC2412K T146 R		C004	404 084 9209	ELECT	4.7U M	50V
	405 014 4608	TR 2SC2412K T146 S			403 051 0607	ELECT	4.7U M	50V
	405 015 8704	TR 2SC2812-L6-TB		C005	404 089 7200	ELECT	100U M	25V
	405 015 8902	TR 2SC2812-L7-TB			403 044 9501	ELECT	100U M	25V
	405 173 9803	TR 2SC3928A1R		C006	404 087 5109	ELECT	470U M	25V
	405 173 9902	TR 2SC3928A1S			403 047 5005	ELECT	470U M	25V
	405 134 5905	TR 2SA1037AK-T146-R		C007	403 057 3107	POLYESTER	0.1U K	50V
	405 147 2205	TR 2SA1037AK-S-T146			403 181 8207	POLYESTER	0.1U K	50V
405 002 0308	TR 2SA1037K T146 R	C008		404 084 8400	ELECT	1000U M	25V	
405 002 0407	TR 2SA1037K T146 S			403 045 1504	ELECT	1000U M	25V	
405 002 6706	TR 2SA1179-M6-TB	C012		403 215 2201	CERAMIC	0.01U K	50V	
Q686	405 002 6904	TR 2SA1179-M7-TB		C1001	404 084 8905	ELECT	10U M	50V
	405 173 9605	TR 2SA1235A1E		403 049 4204	ELECT	10U M	50V	
	405 173 9704	TR 2SA1235A1F	C1002	404 084 8806	ELECT	1U M	50V	
	405 014 4509	TR 2SC2412K T146 R		403 049 0008	ELECT	1U M	50V	
	405 014 4608	TR 2SC2412K T146 S	C101	404 084 8301	ELECT	470U M	16V	
	405 015 8704	TR 2SC2812-L6-TB		403 044 1703	ELECT	470U M	16V	
	405 015 8902	TR 2SC2812-L7-TB	C106	404 084 9308	ELECT	47U M	50V	
	405 173 9803	TR 2SC3928A1R		403 051 3103	ELECT	47U M	50V	
	405 173 9902	TR 2SC3928A1S	C107	404 084 9308	ELECT	47U M	50V	
	405 134 5905	TR 2SA1037AK-T146-R		403 051 3103	ELECT	47U M	50V	
	405 147 2205	TR 2SA1037AK-S-T146	C111	403 215 2201	CERAMIC	0.01U K	50V	
	405 002 0308	TR 2SA1037K T146 R	C112	403 215 2201	CERAMIC	0.01U K	50V	
	405 002 0407	TR 2SA1037K T146 S	C113	403 215 2201	CERAMIC	0.01U K	50V	
	405 002 6706	TR 2SA1179-M6-TB	C120	403 333 5108	CERAMIC	0.033U K	50V	
	405 002 6904	TR 2SA1179-M7-TB	C121	403 215 2201	CERAMIC	0.01U K	50V	
	Q871	405 173 9605	TR 2SA1235A1E	C122	404 084 7809	ELECT	100U M	16V
405 173 9704		TR 2SA1235A1F		403 042 2405	ELECT	100U M	16V	
405 014 4509		TR 2SC2412K T146 R	C123	401 105 7909	MT-GLAZE	0.000 ZA	1/16W	
405 014 4608		TR 2SC2412K T146 S	C132	404 084 8707	ELECT	0.47U M	50V	
405 015 8704		TR 2SC2812-L6-TB		403 048 6308	ELECT	0.47U M	50V	
405 015 8902		TR 2SC2812-L7-TB	C135	404 084 8707	ELECT	0.47U M	50V	
405 173 9803		TR 2SC3928A1R		403 048 6308	ELECT	0.47U M	50V	
405 173 9902		TR 2SC3928A1S	C138	403 284 4304	CERAMIC	0.022U K	50V	
405 014 4509		TR 2SC2412K T146 R	C171	403 113 3805	CERAMIC	1000P K	50V	
405 014 4608		TR 2SC2412K T146 S	C172	403 367 0407	CERAMIC	0.1U K	50V	
405 015 8704		TR 2SC2812-L6-TB	C174	403 157 1904	CERAMIC	10P D	50V	
405 015 8902		TR 2SC2812-L7-TB	C178	404 084 8806	ELECT	1U M	50V	
405 173 9803		TR 2SC3928A1R		403 049 0008	ELECT	1U M	50V	
405 173 9902		TR 2SC3928A1S	C1902	404 087 5406	ELECT	22U M	50V	
405 014 4509		TR 2SC2412K T146 R		403 050 2800	ELECT	22U M	50V	
Q881		405 014 4608	TR 2SC2412K T146 S	C201	404 084 9803	NP-ELECT	1U M	50V
	405 015 8704	TR 2SC2812-L6-TB		403 086 2300	NP-ELECT	1U M	50V	
	405 015 8902	TR 2SC2812-L7-TB	C202	403 058 2604	POLYESTER	0.015U J	50V	
	405 173 9803	TR 2SC3928A1R		403 179 3207	POLYESTER	0.015U J	50V	
	405 173 9902	TR 2SC3928A1S	C203	403 215 2201	CERAMIC	0.01U K	50V	
	405 014 4509	TR 2SC2412K T146 R	C204	404 084 8905	ELECT	10U M	50V	
	405 014 4608	TR 2SC2412K T146 S		403 049 4204	ELECT	10U M	50V	
	405 015 8704	TR 2SC2812-L6-TB	C205	404 084 8905	ELECT	10U M	50V	
	405 015 8902	TR 2SC2812-L7-TB		403 049 4204	ELECT	10U M	50V	
	405 173 9803	TR 2SC3928A1R	C208	403 367 0407	CERAMIC	0.1U K	50V	
	405 173 9902	TR 2SC3928A1S	C209	404 084 8707	ELECT	0.47U M	50V	
	405 014 4509	TR 2SC2412K T146 R		403 048 6308	ELECT	0.47U M	50V	
	405 014 4608	TR 2SC2412K T146 S	C210	404 084 8301	ELECT	470U M	16V	
	405 015 8704	TR 2SC2812-L6-TB		403 051 4209	ELECT	470U M	50V	
	405 015 8902	TR 2SC2812-L7-TB	C211	403 367 0407	CERAMIC	0.1U K	50V	
	405 173 9803	TR 2SC3928A1R	C212	403 155 4204	CERAMIC	15P J	50V	
Q886	405 173 9902	TR 2SC3928A1S	C221	403 305 3507	CERAMIC	0.1U Z	50V	
	405 014 4509	TR 2SC2412K T146 R	C222	403 305 3507	CERAMIC	0.1U Z	50V	
	405 014 4608	TR 2SC2412K T146 S						
	405 015 8704	TR 2SC2812-L6-TB						
	405 015 8902	TR 2SC2812-L7-TB						
	405 173 9803	TR 2SC3928A1R						
	405 173 9902	TR 2SC3928A1S						
	405 014 4509	TR 2SC2412K T146 R						
	405 014 4608	TR 2SC2412K T146 S						
	405 015 8704	TR 2SC2812-L6-TB						
	405 015 8902	TR 2SC2812-L7-TB						
	405 173 9803	TR 2SC3928A1R						
	405 173 9902	TR 2SC3928A1S						
	405 014 4509	TR 2SC2412K T146 R						
	405 014 4608	TR 2SC2412K T146 S						
	405 015 8704	TR 2SC2812-L6-TB						
405 015 8902	TR 2SC2812-L7-TB							
405 173 9803	TR 2SC3928A1R							
405 173 9902	TR 2SC3928A1S							
INTEGRATED CIRCUIT								
IC001	409 472 4408	IC LA4266						
IC201	409 517 5902	IC LA76818A						
IC202	409 241 5407	IC BA178M05T						
	409 265 4806	IC L78M05CV						
	409 172 1509	IC MC78M05CT						
IC501	409 320 5700	IC UPC78M05AHF						
	409 449 4103	IC LA78040						
	409 507 0900	IC LA78040N						
IC651	409 241 5407	IC BA178M05T						
	409 265 4806	IC L78M05CV						
	409 172 1509	IC MC78M05CT						

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C223	403 305 3507	CERAMIC 0.1U Z 50V	C613	403 178 9408	POLYESTER 0.012U J 50V
C224	403 367 0407	CERAMIC 0.1U K 50V		403 249 8903	MT-COMPO 0.012U J 50V
C225	404 084 8806	ELECT 1U M 50V	C614	403 056 9704	POLYESTER 0.01U J 50V
	403 049 0008	ELECT 1U M 50V		403 178 9309	POLYESTER 0.01U J 50V
C226	404 084 8806	ELECT 1U M 50V	△C628	404 073 5106	CERAMIC 470P K 250V
	403 049 0008	ELECT 1U M 50V		404 073 3300	CERAMIC 470P M 250V
C230	403 215 2201	CERAMIC 0.01U K 50V	△C629	404 073 2709	CERAMIC 2200P M 250V
C231	403 260 2904	MT-COMPO 0.33U J 50V		404 073 2808	CERAMIC 2200P M 250V
C232	403 260 2904	MT-COMPO 0.33U J 50V		404 008 4105	CERAMIC 2200P M 400V
C233	404 084 8905	ELECT 10U M 50V		404 071 4200	CERAMIC 2200P M 400V
	403 049 4204	ELECT 10U M 50V	C631	403 247 5003	CERAMIC 470P K 1K
C234	403 215 2201	CERAMIC 0.01U K 50V		403 269 1809	CERAMIC 470P K 1K
C243	403 215 2201	CERAMIC 0.01U K 50V	C633	403 247 5003	CERAMIC 470P K 1K
C244	404 092 8706	ELECT 470U M 50V		403 269 1809	CERAMIC 470P K 1K
	403 051 4209	ELECT 470U M 50V	C634	403 247 5003	CERAMIC 470P K 1K
C245	404 084 9803	NP-ELECT 1U M 50V		403 269 1809	CERAMIC 470P K 1K
	403 086 2300	NP-ELECT 1U M 50V	C641	404 073 9005	ELECT 220U M 160V
C246	404 084 8806	ELECT 1U M 50V	C643	404 084 9506	ELECT 470U M 35V
	403 049 0008	ELECT 1U M 50V		403 054 1502	ELECT 470U M 35V
C247	404 084 9001	ELECT 2.2U M 50V	C644	404 084 8400	ELECT 1000U M 25V
	403 049 9803	ELECT 2.2U M 50V		403 045 1504	ELECT 1000U M 25V
C273	403 164 0204	CERAMIC 0.1U Z 25V	C651	404 091 5409	ELECT 1000U M 10V
C283	403 215 2201	CERAMIC 0.01U K 50V		403 039 9004	ELECT 1000U M 10V
C358	404 084 8806	ELECT 1U M 50V	C661	404 084 8806	ELECT 1U M 50V
	403 049 0008	ELECT 1U M 50V		403 049 0008	ELECT 1U M 50V
C432	403 075 7101	CERAMIC 1000P K 500V	C662	404 084 7908	ELECT 1000U M 16V
C433	403 076 3102	CERAMIC 3900P K 500V		403 042 4805	ELECT 1000U M 16V
C434	404 087 6007	ELECT 47U M 35V	C685	404 084 8806	ELECT 1U M 50V
	403 054 0703	ELECT 47U M 35V		403 049 0008	ELECT 1U M 50V
C435	404 077 3108	MT-POLYPRO 7500P H 1.5K	C801	403 155 4204	CERAMIC 15P J 50V
	403 343 8007	MT-POLYPRO 7500P H 1.5K	C802	403 157 2505	CERAMIC 27P J 50V
C441	403 079 0108	MT-POLYPRO 0.39U J 200V	C803	403 215 2201	CERAMIC 0.01U K 50V
	403 346 7403	MT-POLYPRO 0.39U J 250V	C805	404 084 7700	ELECT 10U M 16V
C469	404 084 8905	ELECT 10U M 50V		403 041 8804	ELECT 10U M 16V
	403 049 4204	ELECT 10U M 50V	C823	403 342 3300	CERAMIC 0.1U K 25V
C471	404 056 5307	NP-ELECT 2.2U M 100V	C824	403 367 0407	CERAMIC 0.1U K 50V
	404 084 9902	NP-ELECT 2.2U M 100V	C825	403 157 3601	CERAMIC 100P J 50V
C482	403 052 8503	ELECT 1000U M 35V	C829	403 342 3300	CERAMIC 0.1U K 25V
C486	404 087 6106	ELECT 22U M 100V	C835	404 084 8806	ELECT 1U M 50V
	403 115 0802	ELECT 22U M 100V		403 049 0008	ELECT 1U M 50V
C491	403 076 5304	CERAMIC 680P K 500V	C851	403 157 3106	CERAMIC 56P J 50V
C510	404 088 7300	ELECT 22U M 16V	C852	403 157 3106	CERAMIC 56P J 50V
	403 042 7707	ELECT 22U M 16V	C853	403 157 3106	CERAMIC 56P J 50V
C514	404 084 8905	ELECT 10U M 50V	C861	404 084 8806	ELECT 1U M 50V
	403 049 4204	ELECT 10U M 50V		403 049 0008	ELECT 1U M 50V
C515	404 084 8400	ELECT 1000U M 25V	C888	403 155 2200	CERAMIC 3300P K 50V
	403 045 1504	ELECT 1000U M 25V	C892	403 342 3300	CERAMIC 0.1U K 25V
C517	404 084 9407	ELECT 220U M 35V	C893	404 084 9001	ELECT 2.2U M 50V
	403 053 2104	ELECT 220U M 35V		403 049 9803	ELECT 2.2U M 50V
C518	403 072 9405	CERAMIC 3300P K 50V	C894	403 281 5007	CERAMIC 0.033U K 25V
C521	404 084 9506	ELECT 470U M 35V			
	403 054 1502	ELECT 470U M 35V	<b>RESISTOR</b>		
C524	403 064 1202	POLYESTER 0.1U K 100V	R003	401 113 5607	MT-GLAZE 750 JA 1/16W
	403 276 9706	POLYESTER 0.1U K 100V	R004	401 105 0702	MT-GLAZE 100K JA 1/16W
△C601	404 060 7205	MT-POLYEST 0.1U M 250V	R005	401 024 9008	CARBON 120 JA 1/6W
	404 093 6107	MT-POLYEST 0.1U M 275V	R006	401 024 5604	CARBON 1 JA 1/6W
△C602	404 060 7205	MT-POLYEST 0.1U M 250V	R010	401 105 1501	MT-GLAZE 1.5K JA 1/16W
	404 093 6107	MT-POLYEST 0.1U M 275V	R011	401 105 2102	MT-GLAZE 18K JA 1/16W
C607	404 038 1600	ELECT 100U M 400V	R1001	401 027 6608	CARBON 75 JA 1/6W
	404 067 4009	ELECT 100U M 400V	R1002	401 024 7004	CARBON 1K JA 1/6W
C608	403 247 6505	CERAMIC 680P K 1K	R1003	401 024 7707	CARBON 100K JA 1/6W
	403 271 9800	CERAMIC 680P K 1K	R103	401 061 8101	OXIDE-MT 39K JA 1W
C610	404 084 8806	ELECT 1U M 50V	R106	401 024 6700	CARBON 100 JA 1/6W
	403 049 0008	ELECT 1U M 50V	R107	401 024 6700	CARBON 100 JA 1/6W
C611	403 247 1609	CERAMIC 220P K 1K	R108	401 105 2102	MT-GLAZE 18K JA 1/16W
C612	403 237 8007	MT-COMPO 0.1U J 50V	R109	401 105 8203	MT-GLAZE 68K JA 1/16W
	403 243 6806	MT-COMPO 0.1U J 50V	R111	401 105 0504	MT-GLAZE 1K JA 1/16W

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R112	401 105 6001	MT-GLAZE 5.6K JA 1/16W	R512	401 020 0801	CARBON 470 JA 1/4W
R114	401 105 4007	MT-GLAZE 330 JA 1/16W	R514	401 024 9701	CARBON 12K JA 1/6W
R115	401 027 2105	CARBON 56 JA 1/6W	R515	401 026 1307	CARBON 27K JA 1/6W
R116	401 105 5806	MT-GLAZE 56 JA 1/16W	R516	401 024 7400	CARBON 10K JA 1/6W
R130	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R518	401 006 8807	CARBON 1.8 JA 1/2W
R132	401 105 5202	MT-GLAZE 470 JA 1/16W	R522	401 025 7409	CARBON 220 JA 1/6W
R140	401 105 5905	MT-GLAZE 560 JA 1/16W	R525	401 008 0908	CARBON 180 JA 1/2W
R141	401 105 5905	MT-GLAZE 560 JA 1/16W	R602	402 060 8109	WIRE WOUND 3.9 KA 5W
R176	401 105 0603	MT-GLAZE 10K JA 1/16W		402 095 6101	WIRE WOUND 3R9 KA 5W
R185	401 068 1600	OXIDE-MT 4.7 JA 2W	R603	401 010 9203	CARBON 560K JA 1/2W
R1902	401 105 1105	MT-GLAZE 12K JA 1/16W	R604	401 066 9103	OXIDE-MT 27 JA 2W
R1903	401 105 6001	MT-GLAZE 5.6K JA 1/16W	R605	401 010 9203	CARBON 560K JA 1/2W
R1904	401 105 4601	MT-GLAZE 3.9K JA 1/16W	R606	401 027 0507	CARBON 470K JA 1/6W
R1905	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R607	401 019 9600	CARBON 47 JA 1/4W
R1906	401 105 2003	MT-GLAZE 1.8K JA 1/16W	R609	401 025 8208	CARBON 22K JA 1/6W
R1907	401 024 6700	CARBON 100 JA 1/6W	R611	401 025 8208	CARBON 22K JA 1/6W
R1911	401 105 2706	MT-GLAZE 220 JA 1/16W	R612	402 001 8502	FUSIBLE RES 10 J- 1/2W
R1912	401 105 2706	MT-GLAZE 220 JA 1/16W	R613	401 064 3806	OXIDE-MT 1.0 JA 2W
R1913	401 105 2706	MT-GLAZE 220 JA 1/16W	R615	401 016 1508	CARBON 22 JA 1/4W
R209	401 113 9506	MT-GLAZE 620K JA 1/16W	R616	401 024 7400	CARBON 10K JA 1/6W
R210	401 105 3703	MT-GLAZE 3K JA 1/16W	R617	402 001 8106	FUSIBLE RES 680 J- 1/4W
R211	401 025 1308	CARBON 150 JA 1/6W	R618	401 024 7004	CARBON 1K JA 1/6W
R212	401 025 1308	CARBON 150 JA 1/6W	R619	401 025 8208	CARBON 22K JA 1/6W
R221	401 105 0504	MT-GLAZE 1K JA 1/16W	R620	401 020 0801	CARBON 470 JA 1/4W
R222	401 105 0504	MT-GLAZE 1K JA 1/16W	△R628	402 000 8305	SOLID 5.6M KA 1/2W
R223	401 105 0504	MT-GLAZE 1K JA 1/16W	△R629	402 000 8305	SOLID 5.6M KA 1/2W
R224	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R635	401 007 2309	CARBON 100K JA 1/2W
R225	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R636	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R226	401 105 3406	MT-GLAZE 27K JA 1/16W	R637	401 007 9308	CARBON 150K JA 1/2W
R227	401 105 4205	MT-GLAZE 33K JA 1/16W	R638	401 061 4400	OXIDE-MT 33K JA 1W
R228	401 024 7707	CARBON 100K JA 1/6W	R639	401 013 6407	CARBON 12K JA 1/4W
R229	401 105 6704	MT-GLAZE 680K JA 1/16W	R643	402 022 2008	FUSIBLE RES 1.0 J- 1/2W
R230	401 026 9303	CARBON 47 JA 1/6W	R644	401 142 9508	OXIDE-MT 0.27 JA 1W
R243	401 068 3703	OXIDE-MT 470 JA 2W	R645	401 026 3905	CARBON 330 JA 1/6W
R244	401 105 5400	MT-GLAZE 47K JA 1/16W	R646	401 026 1307	CARBON 27K JA 1/6W
R245	401 105 5400	MT-GLAZE 47K JA 1/16W	R661	401 060 7402	OXIDE-MT 270 JA 1W
R271	401 105 0405	MT-GLAZE 100 JA 1/16W	R662	401 066 3002	OXIDE-MT 2.2 JA 2W
R272	401 105 0405	MT-GLAZE 100 JA 1/16W	R663	401 013 6407	CARBON 12K JA 1/4W
R280	401 024 6700	CARBON 100 JA 1/6W	R681	401 024 7004	CARBON 1K JA 1/6W
R282	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R682	401 025 8208	CARBON 22K JA 1/6W
R284	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R683	401 105 6100	MT-GLAZE 560K JA 1/16W
R286	401 203 9904	MT-GLAZE 4.7K FA 1/16W	R684	401 105 0603	MT-GLAZE 10K JA 1/16W
R340	401 105 7503	MT-GLAZE 82K JA 1/16W	R685	401 105 2904	MT-GLAZE 22K JA 1/16W
R351	401 027 8602	CARBON 8.2K JA 1/6W	R686	401 012 7009	CARBON 10K JA 1/4W
R352	401 012 7009	CARBON 10K JA 1/4W	R687	401 019 1901	CARBON 3.9K JA 1/4W
R354	401 025 8208	CARBON 22K JA 1/6W	R688	401 025 8208	CARBON 22K JA 1/6W
R355	401 015 3800	CARBON 18K JA 1/4W	R689	401 027 3201	CARBON 560K JA 1/6W
R356	401 105 0603	MT-GLAZE 10K JA 1/16W	R801	401 105 3505	MT-GLAZE 270K JA 1/16W
R357	401 026 7002	CARBON 3.9K JA 1/6W	R804	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R358	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R805	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R422	401 020 2904	CARBON 47K JA 1/4W	R811	401 105 0603	MT-GLAZE 10K JA 1/16W
R423	401 022 4104	CARBON 68K JA 1/4W	R813	401 105 0603	MT-GLAZE 10K JA 1/16W
R424	401 024 7004	CARBON 1K JA 1/6W	R814	401 105 0603	MT-GLAZE 10K JA 1/16W
R426	401 024 7400	CARBON 10K JA 1/6W	R815	401 105 0603	MT-GLAZE 10K JA 1/16W
R432	401 024 7004	CARBON 1K JA 1/6W	R816	401 105 0603	MT-GLAZE 10K JA 1/16W
R433	401 007 1104	CARBON 1K JA 1/2W	R817	401 105 0504	MT-GLAZE 1K JA 1/16W
R434	401 009 5803	CARBON 330 JA 1/2W	R818	401 024 7004	CARBON 1K JA 1/6W
R441	401 064 8702	OXIDE-MT 1K JA 2W	R819	401 105 0603	MT-GLAZE 10K JA 1/16W
R445	401 068 7800	OXIDE-MT 560 JA 2W	R821	401 105 0603	MT-GLAZE 10K JA 1/16W
R475	401 009 5803	CARBON 330 JA 1/2W	R822	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R477	401 058 1108	OXIDE-MT 10 JA 1W	R830	401 105 0504	MT-GLAZE 1K JA 1/16W
R479	401 025 7805	CARBON 2.2K JA 1/6W	R831	401 105 5202	MT-GLAZE 470 JA 1/16W
R481	401 064 5701	OXIDE-MT 1.8 JA 2W	R833	401 105 0603	MT-GLAZE 10K JA 1/16W
R488	402 022 2008	FUSIBLE RES 1.0 J- 1/2W	R834	401 105 0603	MT-GLAZE 10K JA 1/16W
R501	401 066 1404	OXIDE-MT 1.8K JA 2W	R835	401 105 0603	MT-GLAZE 10K JA 1/16W
R510	401 025 8208	CARBON 22K JA 1/6W	R836	401 105 0603	MT-GLAZE 10K JA 1/16W
R511	401 024 7400	CARBON 10K JA 1/6W	R837	401 105 1600	MT-GLAZE 15K JA 1/16W

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R838	401 105 1600	MT-GLAZE 15K JA 1/16W	D1002TM	407 063 9603	ZENER DIODE MTZJ9.1A
R839	401 105 4007	MT-GLAZE 330 JA 1/16W		407 057 9602	ZENER DIODE RD9.1EB1
R840	401 105 4007	MT-GLAZE 330 JA 1/16W		407 162 2703	ZENER DIODE UZ-9.1BCB
R841	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D102	407 099 5600	ZENER DIODE MTZJ6.8A
R842	401 105 5301	MT-GLAZE 4.7K JA 1/16W		407 057 4003	ZENER DIODE RD6.8EB1
R851	401 025 1605	CARBON 1.5K JA 1/6W		408 047 8605	ZENER DIODE MTZJ6.8A
R853	401 027 8602	CARBON 8.2K JA 1/6W	D103	407 100 0204	ZENER DIODE MTZJ36A
R855	401 027 8602	CARBON 8.2K JA 1/6W		407 056 2307	ZENER DIODE RD36EB1
R857	401 027 8602	CARBON 8.2K JA 1/6W		408 047 6205	ZENER DIODE MTZJ36A
R861	401 105 1501	MT-GLAZE 1.5K JA 1/16W	D122	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R862	401 105 7404	MT-GLAZE 8.2K JA 1/16W	D1910	407 116 6504	LED SLP-181B-51
R863	401 105 5400	MT-GLAZE 47K JA 1/16W	D1910A	610 264 5064	HOLDER LED-S2CP
R866	401 024 6700	CARBON 100 JA 1/6W		610 273 7929	HOLDER LED-S4KF
R869	401 024 6700	CARBON 100 JA 1/6W		610 303 9954	HOLDER LED-C4LA
R870	401 105 2904	MT-GLAZE 22K JA 1/16W	D249	407 099 6003	ZENER DIODE MTZJ9.1B
R871	401 105 0603	MT-GLAZE 10K JA 1/16W		407 057 9701	ZENER DIODE RD9.1EB2
R872	401 026 1307	CARBON 27K JA 1/6W	D352	407 063 8705	ZENER DIODE MTZJ5.1C
R873	401 105 4205	MT-GLAZE 33K JA 1/16W		407 056 9801	ZENER DIODE RD5.6EB1
R874	401 105 0603	MT-GLAZE 10K JA 1/16W		408 047 7103	ZENER DIODE MTZJ5.1C-52
R875	401 105 5400	MT-GLAZE 47K JA 1/16W	D357	407 005 4505	DIODE DS442X
R877	403 157 7203	CERAMIC 3900P K 50V		408 008 2406	DIODE 1N4148
R881	401 105 4106	MT-GLAZE 3.3K JA 1/16W		407 012 4406	DIODE 1SS133
R882	401 105 4106	MT-GLAZE 3.3K JA 1/16W		407 013 4306	DIODE 1S2076A
R883	401 105 4205	MT-GLAZE 33K JA 1/16W		407 013 7109	DIODE 1S2473
R886	401 105 2904	MT-GLAZE 22K JA 1/16W	D421	407 099 7208	ZENER DIODE MTZJ16A
R892	401 105 5509	MT-GLAZE 470K JA 1/16W		407 054 7007	ZENER DIODE RD16EB1
R893	401 105 8005	MT-GLAZE 1M JA 1/16W		407 054 7205	ZENER DIODE RD16EB3
R894	401 105 0405	MT-GLAZE 100 JA 1/16W		408 047 5307	ZENER DIODE MTZJ16A-52
<b>VARIABLE RESISTOR</b>			D432	407 009 8905	DIODE RU3M
VR631	645 006 5125	VR, SEMI, 2K N	D467	408 008 2406	DIODE 1N4148
	652 000 0100	VR, SEMI, 2K N		407 013 4306	DIODE 1S2076A
<b>TRANSFORMER</b>				407 013 6508	DIODE 1S2471
T431	652 001 1144	TRANS, DRIVE	D468	407 012 4406	DIODE 1SS133
△T471	645 057 4832	TRANS, FLYBACK	D476	407 099 5600	ZENER DIODE MTZJ6.8A
△T611	645 058 8051	TRANS, POWER, PULSE		407 057 4003	ZENER DIODE RD6.8EB1
<b>COIL</b>				408 047 8605	ZENER DIODE MTZJ6.8A
L171	645 049 3379	TRANS, OSC, 38MHZ	D485	407 007 7405	DIODE EU1
	645 054 0271	TRANS, OSC, 38MHZ	D512	407 005 8602	DIODE ERA15-02
L234	401 024 9008	CARBON 120 JA 1/6W	D603	407 006 6300	DIODE ERC05-10B
L235	401 024 9008	CARBON 120 JA 1/6W	D604	407 006 6300	DIODE ERC05-10B
L236	401 024 9008	CARBON 120 JA 1/6W	D605	407 006 6300	DIODE ERC05-10B
L431	610 031 9998	PIPE CORE	D606	407 006 6300	DIODE ERC05-10B
	645 018 7025	CORE, PIPE	△D610	407 230 3908	PHOTO COUPLE PC123Y52
	652 001 0475	PIPE CORE		407 231 7707	PC TLP421F (D4-BL)
L432	610 031 9998	PIPE CORE	D611	407 012 4406	DIODE 1SS133
	645 018 7025	CORE, PIPE	D613	407 063 9702	ZENER DIODE MTZJ9.1C
	652 001 0475	PIPE CORE		407 057 9800	ZENER DIODE RD9.1EB3
L441	610 210 8071	LINEARITY COIL		408 048 0400	ZENER DIODE MTZJ9.1C-52
△L601	610 031 5945	LINE FILTER	D617	407 006 0100	DIODE ERA91-02
	610 031 5969	LINE FILTER	D631	407 009 8806	DIODE RU3AM
	645 018 9265	LINE FILTER	D633	407 007 7603	DIODE EU2
L603	645 018 9722	CORE, PIPE		407 007 7801	DIODE EU2Z
	652 001 0147	CORE, PIPE	D634	407 009 8905	DIODE RU3M
L604	645 018 9722	CORE, PIPE	D661	407 099 6102	ZENER DIODE MTZJ10B
	652 001 0147	CORE, PIPE		407 054 0008	ZENER DIODE RD10EB2
L605	645 005 0763	CORE, PIPE		408 047 2306	ZENER DIODE MTZJ10B-52
L631	645 018 9722	CORE, PIPE	D681	407 149 0807	DIODE 1SS355-TE-17
	652 001 0147	CORE, PIPE	D683	407 005 4505	DIODE DS442X
<b>DIODE</b>				408 008 2406	DIODE 1N4148
D005	407 149 0807	DIODE 1SS355-TE-17		407 012 4406	DIODE 1SS133
D1001TM	407 063 9603	ZENER DIODE MTZJ9.1A		407 013 4306	DIODE 1S2076A
	407 057 9602	ZENER DIODE RD9.1EB1		407 013 7109	DIODE 1S2473
	407 162 2703	ZENER DIODE UZ-9.1BCB	D685	407 099 5600	ZENER DIODE MTZJ6.8A
				407 057 4003	ZENER DIODE RD6.8EB1
				408 047 8605	ZENER DIODE MTZJ6.8A
			D686	407 099 5501	ZENER DIODE MTZJ6.2C
				407 057 2801	ZENER DIODE RD6.2EB3


Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
D861	408 047 8308	ZENER DIODE MTZJ6.2C-52		405 002 0407	TR 2SA1037K T146 S
	407 055 7907	ZENER DIODE RD3.6EL		405 002 6706	TR 2SA1179-M6-TB
	408 041 2005	ZENER DIODE RD3.6EL		405 002 6904	TR 2SA1179-M7-TB
<b>MISCELLANEOUS</b>				405 173 9605	TR 2SA1235A1E
△ F601	423 028 8603	FUSE 250V 4A		405 173 9704	TR 2SA1235A1F
	423 024 8409	FUSE 250V 4A	<b>CAPACITOR</b>		
	423 007 2103	FUSE 250V 4A	C703	403 157 6503	CERAMIC 390P K 50V
F601A	645 040 3576	HOLDER, FUSE	C705	403 157 6404	CERAMIC 330P K 50V
F601B	645 040 3576	HOLDER, FUSE	C707	403 157 6404	CERAMIC 330P K 50V
A101	645 057 2753	TUNER, U/V	C708	404 084 6505	CERAMIC 1000P K 2K
	645 061 4132	TUNER, U/V		403 077 2708	CERAMIC 1000P P 2K
A1901A	645 047 6228	UNIT, REMOCON RECEIVER		403 077 2807	CERAMIC 1000P Z 2K
K1002	645 061 4248	JACK, RCA-2		403 312 8304	CERAMIC 1000P Z 2K
	652 001 2226	JACK, RCA-2	C710	403 368 8907	ELECT 4.7U M 250V
K1003	645 040 1275	JACK, RCA-2	C751	404 084 7809	ELECT 100U M 16V
	652 001 2202	JACK, RCA-2		403 042 2405	ELECT 100U M 16V
PS601	408 046 4400	THERMISTOR PTDA1BF9R0Q20	<b>RESISTOR</b>		
SW1901	645 003 4701	SWITCH, PUSH 1P-1TX1	R701	401 105 1402	MT-GLAZE 150 JA 1/16W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R702	401 025 1308	CARBON 150 JA 1/6W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R704	401 105 1402	MT-GLAZE 150 JA 1/16W
SW1902	645 003 4701	SWITCH, PUSH 1P-1TX1	R705	401 025 1308	CARBON 150 JA 1/6W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R707	401 105 1402	MT-GLAZE 150 JA 1/16W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R708	401 025 1308	CARBON 150 JA 1/6W
SW1903	645 003 4701	SWITCH, PUSH 1P-1TX1	R710	401 057 3103	OXIDE-MT 0.22 JA 1W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R711	401 065 4604	OXIDE-MT 12K JA 2W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R712	401 065 4604	OXIDE-MT 12K JA 2W
SW1904	645 003 4701	SWITCH, PUSH 1P-1TX1	R713	401 065 4604	OXIDE-MT 12K JA 2W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R715	401 009 1508	CARBON 2.7K JA 1/2W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R716	401 009 1508	CARBON 2.7K JA 1/2W
SW1905	645 003 4701	SWITCH, PUSH 1P-1TX1	R717	401 009 1508	CARBON 2.7K JA 1/2W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R723	401 105 2003	MT-GLAZE 1.8K JA 1/16W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R724	401 026 9600	CARBON 470 JA 1/6W
SW1906	645 003 4701	SWITCH, PUSH 1P-1TX1	R743	401 024 7400	CARBON 10K JA 1/6W
	645 019 4887	SWITCH, PUSH 1P-1TX1	R751	401 105 0603	MT-GLAZE 10K JA 1/16W
	645 027 7382	SWITCH, PUSH 1P-1TX1	R752	401 105 0603	MT-GLAZE 10K JA 1/16W
△ SW601	645 059 0061	SWITCH, POWER 1P-1TX1	R753	401 105 0603	MT-GLAZE 10K JA 1/16W
△ VA601	407 171 2008	VARISTOR ERZV14D471	<b>COIL</b>		
X161	421 009 4606	SAW F TSF5419P	L702	645 007 9337	INDUCTOR, 270U K
X211	645 024 8818	OSC, CRYSTAL 4.433619MHZ	<b>DIODE</b>		
	652 001 0154	OSC, CRYSTAL 4.433619MHZ	D741	407 149 0807	DIODE 1SS355-TE-17
X801	645 004 1938	OSC, CRYSTAL 32.768KHZ	D742	407 149 0807	DIODE 1SS355-TE-17
	645 004 1945	OSC, CRYSTAL 32.768KHZ	D751	407 149 0807	DIODE 1SS355-TE-17
<b>610 312 2083 ASSY,PWB,CRT C4MV 1AA0B10S1330B</b>			D752	407 149 0807	DIODE 1SS355-TE-17
<b>TRANSISTOR</b>			D753	407 149 0807	DIODE 1SS355-TE-17
Q701	405 041 6507	TR 2SC2621-D-RA	D754	407 149 0807	DIODE 1SS355-TE-17
	405 041 6705	TR 2SC2621-E-RA	<b>MISCELLANEOUS</b>		
	405 066 9903	TR 2SC2688(1)-K	△ K701L	645 026 2005	SOCKET, CRT 8P
	405 067 0008	TR 2SC2688(1)-L			
	405 067 0107	TR 2SC2688(1)-M			
Q703	405 041 6507	TR 2SC2621-D-RA			
	405 041 6705	TR 2SC2621-E-RA			
	405 066 9903	TR 2SC2688(1)-K			
	405 067 0008	TR 2SC2688(1)-L			
	405 067 0107	TR 2SC2688(1)-M			
Q705	405 041 6507	TR 2SC2621-D-RA			
	405 041 6705	TR 2SC2621-E-RA			
	405 066 9903	TR 2SC2688(1)-K			
	405 067 0008	TR 2SC2688(1)-L			
	405 067 0107	TR 2SC2688(1)-M			
Q721	405 001 7407	TR 2SA1015-O(SAN)			
	405 001 7605	TR 2SA1015-Y(SAN)			
Q751	405 002 0308	TR 2SA1037K T146 R			





[illegible]

## MAIN BOARD (Component Location)



**(On the Main Board)**

IC201 (IF/VIDEO/CHROMA)																	
Pin-1	2.3V	2	2.2V	3	2.7V	4	3.2V	5	2.9V	6	2.9V	7	0V	8	5.0V	9	2.5V
10	2.3V	11	4.3V	12	4.1V	13	4.3V	14	1.6V	15	1.7V	16	1.6V	17	0V	18	8.3V
19	2.2V	20	2.1V	21	2.1V	22	2.0V	23	2.2V	24	2.7V	25	5.2V	26	2.6V	27	0.7V
28	1.3V	29	1.7V	30	0.9V	31	4.5V	32	8.4V	33	0V	34	2.5V	35	2.5V	36	2.7V
37	1.9V	38	2.8V	39	3.5V	40	2.5V	41	0V	42	2.5V	43	5.0V	44	2.7V	45	2.5V
46	2.3V	47	3.8V	48	4.1V	49	4.1V	50	2.5V	51	2.2V	52	2.0V	53	2.2V	54	3.1V

IC501 (VERT. OUT)													
Pin-1	2.9V	2	26.4V	3	1.6V	4	0V	5	18.0V	6	27.0V	7	2.9V

IC001 (AUDIO AMP.)																	
Pin-1	N.C.	2	N.C.	3	7.1V	4	GND	5	0.7V	6	1.2V	7	6.8V	8	GND	9	14.4V
10	N.C.																


<b>IC202</b>					<b>IC651</b>						
Pin-1	7.8V	2	GND	3	5.0V	Pin-1	12.5V	2	GND	3	5.0V

IC802 (MEMORY)															
Pin-1	GND	2	GND	3	GND	4	GND	5	5.0V	6	5.0V	7	GND	8	5.0V

IC801 (CPU)																	
Pin-1	4.3V	2	4.1V	3	5.0V	4	5.0V	5	0V	6	1.9V	7	2.3V	8	5.0V	9	-
10	2.3V	11	3.4V	12	0V	13	5.0V	14	3.4V	15	5.0V	16	0V	17	4.8V	18	4.2V
19	0V	20	0V	21	0V	22	0V	23	5.0V	24	0V	25	0V	26	-	27	4.4V
28	5.0V	29	0V	30	5.0V	31	4.9V	32	5.0V	33	5.0V	34	0V	35	5.0V	36	5.0V

<b>Q111</b>	<b>Q261</b>	<b>Q431</b>	<b>Q432</b>	<b>Q611</b>	<b>Q612</b>	<b>Q613</b>	<b>Q631</b>	<b>Q661</b>	<b>Q681</b>	<b>Q684</b>	<b>Q685</b>	<b>Q686</b>
B 1.3V	B 2.3V	B 0V	B 2.1V	B 15.0V	B 0V	B -0.3V	B 0.2V	B 16.0V	B 0V	B 0.1V	B 0.3V	B 19.0V
C 6.0V	C 0V	C 17.5V	C 133.7V	C 0V	C -0.3V	C 314V	C 18.5V	C -1.0V	C 5.1V	C 0V	C 19.0V	C 0V
E 0.5V	E 3.0V	E 0V	E 2.2V	E 15.2V	E 0V	E 0V	E 3.3V	E 14.9V	E 0V	E 0V	E 0.2V	E 18.5V

<b>Q861</b>	<b>Q871</b>	<b>Q881</b>	<b>Q886</b>
B 4.4V	B -8.6V	B -0.4V	B 0.7V
C 5.0V	C 4.8V	C 4.2V	C 0V
E 5.0V	E 0V	E 0V	E 0V



**(On the CRT Board)**

<b>Q701</b>	<b>Q705</b>	<b>Q703</b>	<b>Q721</b>	<b>Q751</b>
B 2.5V	B 2.5V	B 2.5V	B 0.7V	B 9.3V
C 141V	C 141V	C 141.8V	C GND	C 0V
E 2.3V	E 2.3V	E 2.3V	E 1.4V	E 9.2V

